

**Eternal Lighting Company**

**Premier120 Spot - 120 Watt LED Moving Head**



**[support@EternalLighting.com](mailto:support@EternalLighting.com)**

**832-623-9377**

Premier120 Spot LED Moving Head - Eternal Lighting-832-623-9377

Channel 1= pan

Pan,0,255

Channel 2= upan

Fine Pan,0,255

Channel 3= tilt

Tilt,0,255

Channel 4= utilt

Fine Tilt,0,255

Channel 5= pantilt\_speed

Pan/Tilt Speed,0,255

Channel 6= color

white,0,15

red,16,30

green,31,45

yellow,46,60

blue,61,75

orange,76,90

magenta,91,105

light\_green,106,120

mixed,121,255

Channel 7= gobo

Miscellaneous/open,0,10

Miscellaneous/gobo1,11,20

Miscellaneous/gobo2,21,30

Miscellaneous/gobo3,31,40

Miscellaneous/gobo4,41,50

Miscellaneous/gobo5,51,60

Miscellaneous/gobo6,61,70

Miscellaneous/shake\_gobo6,71,85

Miscellaneous/shake\_gobo5,86,100

Miscellaneous/shake\_gobo4,101,115

Miscellaneous/shake\_gobo3,116,130

Miscellaneous/shake\_gobo2,131,145

Miscellaneous/shake\_gobo1,146,160

Flow Effect,161,255

Channel 8= gobo\_rotate

rotate,0,60

right\_rotate,61,150

no\_function,151,165

left\_rotate,166,255

Channel 9= gobo2

Miscellaneous/open,0,10

Miscellaneous/gobo1,11,20

Miscellaneous/gobo2,21,30

Miscellaneous/gobo3,31,40

Miscellaneous/gobo4,41,50

Miscellaneous/gobo5,51,60

Miscellaneous/gobo6,61,70

Miscellaneous/shake\_gobo6,71,85

Miscellaneous/shake\_gobo5,86,100

Miscellaneous/shake\_gobo4,101,115  
Miscellaneous/shake\_gobo3,116,130  
Miscellaneous/shake\_gobo2,131,145  
Miscellaneous/shake\_gobo1,146,160  
Flow Effect,161,255

Channel 10= gobo\_rotate2  
rotate,0,60  
right\_rotate,61,150  
no\_function,151,165  
left\_rotate,166,255

Channel 11= prism  
open,0,4  
no\_function,5,9  
left\_rotate,10,127  
no\_function,128,132  
right\_rotate,133,255

Channel 12= focus  
focus\_far,0,100  
focus\_mid,101,160  
focus\_near,161,255

Channel 13= zoom  
Zoom 1,0,127  
Zoom 2,128,255

Channel 14= dimmer  
dimmer,0,255

Channel 15= strobe\_speed  
closed,0,31  
open,32,63  
strobe,64,95  
open,96,127  
pulse\_strobe,128,159  
open,160,191  
random\_strobe,192,223  
open,224,255

Channel 16= mode  
no\_function,0,19  
Pan/Tilt Black  
Activate,20,39  
Pan/Tilt Black  
De-Active,40,59  
no\_function,60,139  
auto1,140,149  
auto2,150,159  
TEST,160,169  
custom,170,179  
audio1,180,189  
audio2,190,199  
reset,200,219  
no\_function,220,255